



NOTE: This Drawing should be used in addition to each products respective Installation Manual. (not in place of)

Important: Ensure wiring polarity is consistent from Relay3 to each Aura's Remote Input terminals.

Outside Wall Switch CM-45/455SE1 (or similar)

Inside Wall Switch (always unlocks & opens door)

Inside 'Push-to-Lock' CM-45/855SE1 (or similar)

Aura Dip Switch Settings

Color Select

1	Red	IDL
2	G/B	
3	Red	ACT
4	G/B	

ON →

Enable

4	LOC/REM
3	RELAY
2	SPEAKER
1	ON ←

Camden DOOR CONTROLS

5502 Timberlea Blvd. Mississauga, Ontario L4W 2T7

SCALE: NONE	DRAWN BY: DGW	DATE: 03/07/17	REV: 2
-------------	---------------	----------------	--------

WC-13 Washroom Package Wiring Diagram (normally locked)

DRAWING No: DRG-CX-WC-13-8	FILENAME: WC-13-8 wiring diagram_R2
----------------------------	-------------------------------------

For Normally Unlocked Door, see over...

Part # 40-82D003