



NOTE: This Drawing should be used in addition to each products respective Installation Manual. (not in place of)

Important: Ensure wiring polarity is consistent from Relay3 to each Aura's Remote Input terminals.

Outside Wall Switch
CM-45/455SE1
(or similar)

Inside Wall Switch
(always unlocks & opens door)

Inside 'Push-to-Lock'
CM-45/855SE1
(or similar)

Aura Dip Switch Settings

| Color Select | | Enable | |
|--------------------------|-----|--------|---------|
| 1 | Red | 4 | ON ← |
| 2 | G/B | 3 | LOC/REM |
| 3 | Red | 2 | RELAY |
| 4 | G/B | 1 | SPEAKER |
| IDL (1, 2) ACT (3, 4) | | ON ← | |

| | | | | | |
|--|---------------|-----------------------------|-------------------------------------|---|--|
| | | CAMDEN DOOR CONTROLS | | 5502 Timberlea Blvd. Mississauga, Ontario L4W 2T7 | |
| SCALE: NONE | DRAWN BY: DGW | DATE: 03/07/17 | REV: 2 | | |
| WC-13 Washroom Package Wiring Diagram (normally unlocked) | | | | | |
| DRAWING No: DRG-CX-WC-13-7 | | | FILENAME: WC-13-7 wiring diagram_R2 | | |